






























Machine	Explode	Code	Description
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	1		Support
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	2	AK099	Shelf
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	3		Spring
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	4		Shelf Protector Pin
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	5		Wheel Support
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	6	AG257	Back Wheel
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	7	AK096	Handle
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	8		Door
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	9		Body
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	10		Thermostat Box Cover
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	11	AB363	Thermostat
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	12		Thermostat Support
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	13		Thermostat Box
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	14	AC614	Sensor
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	15	AA639	Sensor Fixed Clip
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	17		Unite Board
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	18	AD202	Condenser
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	19		Condenser Cover Board
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	20	AJ520	Circle Fan & Blade
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	21		Basket Guard Grills
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	22	AG014	Compressor(R600a)
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	23	AK076	Water Box
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	24		Plug
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	25		Air Flow Grille
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	26		Right Ornament L=340
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	26		Right Ornament L=335
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	27		Ornament Clip
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	28		Bottle Cap Box
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	29		Bottle Opener
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	30		Back Ornament L=1637
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	30		Back Ornament L=1632
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	31	AJ506	Lock & Key
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	32		Lock Box
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	33		Left Ornament L=340
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	33		Left Ornament L=335
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	34		Air Conduct Board Right Support
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	35		Air Conduct Board Left Support
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	36	AK102	Evaporator
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	37	AG253	Evaporator Fixer
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	38	AB339	Circle Fan
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	39		Basket Guard Grills
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	40		Fan Support
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	41		Air Conduct Board
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	42	AB120	Filter Drier
CT332 - Polar bovenlader flessen/fustenkoeler 577 liter	N/A	AJ162	Electrics for Compressor HPKD190A